


## EXPLODED VIEW & PARTS LIST

Item No.	Part No.	Component Part	Description	Qty
1	666459		Connecting Rod Assembly	1
2*		624396	Piston Cup	1
3*		625180	Screw-Cup Retainer	1
4		626397	Piston Cup Retainer	1
5*		670031	Cylinder Sleeve	1
6	610869-500		Head	1
7*	623143		O-Ring Head Gasket	1
8*	625175		Screw-Head	4
9	621482-540		Valve Plate Assembly	1
10*		617177	Valve Restraint	1
11*		617562	Valve Keeper Strip	2
12*		621485	Valve Flapper-Int. & Exh.	2
13		621632-540	Valve Plate	1
14*		625094	Screw-Valve Plate	2
15*	623071		O-ring-Valve Plate	1
16	638281		Fan-Black	1

Item No.	Part No.	Description	Qty
30	602657	Pressure Switch	1
31	615779	Sleeve - Self Aligning	1
32	618112	Exhaust Tube	1
33	625826	Unloader Tube	1
34	624925	Fitting	1
35	624273	Drain Cock Assembly	1
36	624361	Elbow - Unloader Tube	1
37	624654	Bumper	1
38	625106	Insert-Unloader Tube	4
39	624511	Insert-Exhaust Tube	1



Item No.	Part No.	Description	Qty
17	647076	Fan Guard	1
18	603178	Capacitor Bracket	1
19	625434	Screw 8/16" x 3/8 Torx	2
20	603025	Capacitor 8mfd/450V	1
21	603167	Capacitor Cover	1
22	625449	Screw 8/32" x 3/8 Torx	2
23	633160	Strain Relief Bushing	1
24	660710	Filter Body	1
25	641034	Filter-Foam	1
26	660767	Filter-Body Cap	1
27	629081	Handle	1
28	625379	Screw-Handle	2
29	626014	Washer-Handle	2

\* Parts included in Rebuild Kit part number 1904

Item No.	Part No.	Description	Qty
40	624484	Connector - Head	1
41	625206	Screw-Cprsr. Mounting	4
42	626563	Washer-Cprsr. Mounting	4
43	626509	Lock Washer-Cprsr. Mtrng.	4
44	626766	Nut - Compression	1
45	625406	Screw - Bumper	4
46	633660	Cord	1
47	633957	Safety Valve	1
48	638262	Gauge - Pressure	1
49	638322	Check Valve Assembly	1
50	669470-540	Tank Assembly	1