


EXPLODED VIEW & PARTS LIST

Key	Part No.	Description	Qty.
1	840087	Motor Housing Assembly	1
2	808162	Start Capacitor 188-227 mfd	1
3	803165	Capacitor Cover - Small	1
4	803163	Run Capacitor 45 mfd	1
5	803164	Capacitor Cover - Large	1
6	804485	Switch - Motor	1
7	828764	Key - Square 3/16 x .46"	1
8	807810	Ecc. Brg., Rod & Sleeve Assy.	1
9	826008	Set Screw 5/16-18	2
10*	828183	Piston Cup	1
11	828180	Cup Retainer	1
12*	826170	Screw 1/4x20 x 7/8" Flat Head	2
13*	818183	Cylinder Sleeve	1
14	882404	Deflector Cover	1
16	826182	Screw #10-24 x .6" Pan Head	8
16	838488	Fan	1
17	826683	Washer #13	1
18	828608	Lookwasher #10	1
18	882405	Front Cover	1
20*	823075	O-Ring	1
21	882828	Valve Plate - Acrylic Coat	1
22*	882331	Flapper Valve	2
23	817487	Restraint	2
24*	826278	Screw #10-32x3/8"	2
25*	820882	O-Ring Head Gasket	1
26	882501	Head	1
27	826848	Screw #10-24x7/8"	2
28	825171	Head Screw	6
29*	884142	Filter Element	1
30	882141	Filter Cover	1
31	826188	Screw 10-24 7/8"	1
N/E	828577	Wire Clip	1



* Parts included in Rebuild Kit part number 1913

Item No.	Part No.	Description	Qty
1	802852	Pressure Switch	1
2	804228	Hand Grip	2
3	816876	Unloader Tube	1
4	816825	Exhaust Tube	1
5	816912	Sleeve - Self Aligning	1
6	824825	Filling	2
7	828205	Axle	1
8	824273	Drain Cook Assembly	2
8	824381	Elbow - Unloader Tube	1
10	888628	Pipe Plug	1
11	824510	Tubing Insert	1
12	824714	Connector-Head	1
13	825188	Screw - Compressor to Base	3
14	828852	Lookwasher - Compressor to Base	3

Item No.	Part No.	Description	Qty
16	823801	Retaining Ring - Bowd	1
18	823814	Retaining Ring - E Type	1
17	828760	Nut - Self Aligning	1
18	824088	Pipe Reducer Bushing	1
19	888290	Cord	1
20	888282	Gauge - Pressure	2
21	888283	Cheek Valve Assembly	1
22	888628	Safety Valve	1
23	841133	Air Regulator	1
24	882975-540	Tank Assembly	1
26	826408	Screw - Bumpers & Axle	8
28	824854	Bumper	4
27	847228	Wheel	1