


Item No.	Part No.	Component Part	Description	Qty
*1	666973		Connecting Rod Assy	1
2	614509		Front Cover	1
*3	623638		O Ring - Sleeve	1
4	625114		Screw - Connecting Rod	1
5	625354		Screw - Fan	1
6	625646		Screw - Head	6
7	625448		Screw - Front Cover	4
8	626014		Washer - Head & Handle	8
9	626563		Washer - Fan	1
10	626754		Square Key	1
11	633718		Fan	1
*12	636760		O-Ring Gasket - Head	1
13	667172		Ecc. & Bearing Assy	1
14		625008	Set Screw - Eccentric	2
15	662525-540		Valve Plate Assembly	1
16		617124	Valve Restraint	2
17		617135	Valve Keeper	1
18		625446	Screw - Valve Flapper	6
*19		656708	Valve Flapper - Exhaust	4
20		662518-540	Valve Plate	1
*21		656887	Valve Flapper - Intake	1
22	661253-500		Head	1
23	626509		Lockwasher - Fan	1
24	662793-540		Motor End Cap Assembly	1
*25	636415		Dust Shield	1
26	641274		Filter Assembly	1
27		641138	Filter Body	1
28		661833	Filter - Felt	1
29	629117		Handle	1
30	625450		Screw - Handle	2
N/S	644007		Hex Key	1

* Parts Included in Rebuild Kit part number 1902

EXPLODED VIEW & PARTS LIST

Item No.	Part No.	Description	Qty
1	602633	Pressure Switch	1
2	615652	Exhaust Tube	1
3	615953	Unloader Tube	1
4	615912	Sleeve-Self Aligning	1
5	624925	Fitting	6
6	662785-540	Tank Assembly	1
7	624361	Elbow-Unloader Tube	1
8	624273	Drain Cook Assembly	1
9	624510	Tubing Insert	1
10	641133	Air Regulator	1



Item No.	Part No.	Description	Qty
11	624318	Connector - Head	1
12	625613	Screw-Compressor Mtng.	4
13	626025	Lockwasher - Cprsr. Mtng.	4
14	625540	Washer - Cprsr. Mtng.	4
15	624654	Bumper	1
16	625406	Screw - Bumper	4
17	626750	Compression Nut	1
18	633657	Safety Valve	1
19	636263	Check Valve Assembly	1
20	633750	Cord	1
21	636262	Pressure	1